

Operator's



# Spray Star 3185/3186

SharpShooter-Rate Sync w/ Envizo Pro II  
for 18' and 20' Booms

July 2016

**Product Support:**

**Hwy 55 & Poplar Ave; Cameron WI 54822**

**1-800-891-9435    [productsupport@smithco.com](mailto:productsupport@smithco.com)**

# CONTENTS

Introduction

<b>Introduction</b> .....	<b>1-11</b>
Introduction .....	1
Symbols .....	2-3
Safety .....	4
Safety Decal Location .....	5
General Safe Practices .....	6
Safe Spraying Practices .....	7
Specifications .....	8
Optional Spray Equipment .....	8
Set Up .....	9
Controls & Instruments .....	10-11
<b>Operation</b> .....	<b>12-26</b>
Operating Instructions .....	12-14
Envizio Pro II Do's and Don'ts .....	14
SharpShooter-Rate Sync Console Features .....	15
Initial Set Up of Envizio Pro II .....	16-19
SharpShooter-Rate Sync Control .....	20-21
Spray Operation .....	22
Spray Introduction .....	23
Re-Calibration of Flow Meter .....	23
Turf Management .....	24
Hose & Handgun Spraying .....	24
Nozzle Troubleshooting .....	25-26
<b>Reference</b> .....	<b>27-32</b>
Collection Times .....	27
Blended Pulse Tip Selection Guide .....	28
Declaration of Conformity .....	29-30
Quick Reference .....	32

Operation

Spraying Procedures

Nozzle Charts

Reference

Read this manual and all other manuals pertaining to the Spray Star 3180 carefully as they contain safety, operating, assembly and maintenance instructions. Failure to do so could result in personal injury or equipment damage.

Keep manuals in a safe place after operator and maintenance personnel have read them. Right and left sides are from the operator's seat, facing forward.

**WARNING**

**CALIFORNIA**  
**Proposition 65 Warning**  
**Engine exhaust and some of its constituents**  
**are known to the State of California to**  
**cause cancer, birth defects, and other**  
**reproductive harm.**

All **Smithco** machines have a Serial Number and Model Number. Both numbers are needed when ordering parts. The serial number plate on the Spray Star 3180 is located on top of the frame, between the hydro pump and spray tank. Refer to engine manual for placement of engine serial number. Refer to engine manual for placement of engine serial number.

For product and accessory information, help finding a dealer, or to register your product please contact us at [www.Smithco.com](http://www.Smithco.com).

Information needed when ordering replacement parts:

1. Model Number of machine
2. Serial Number of machine
3. Name and Part Number of part
4. Quantity of parts

























For easy access record your Serial and Model numbers here.




















**SMITHCO**  
 WAYNE, PENNSYLVANIA 19087 USA  
 610-688-4009 Fax 610-688-6069

**CE**

SERIAL NO. <input style="width: 90%;" type="text"/>	kW/hp <input style="width: 90%;" type="text"/>	DATE OF MFG. <input style="width: 90%;" type="text"/>
MODEL NO. <input style="width: 90%;" type="text"/>	lb/kg Empty <input style="width: 90%;" type="text"/>	lb/kg Full <input style="width: 90%;" type="text"/>

# SYMBOLS

	Read Operator's Manual		Electrical Power		No Electrical Power
	Engine - Stop		Engine - Start		Engine - Run
	Engine Oil		Temperature Light		Water Temperature
	RPM 1000/mi		Gasoline		Diesel
	Glow Plug - On		Glow Plug - Off		Glow Plug
	Hour Meter		Hour Meter		Fuse
	Hand Throttle		Choke - Closed		Choke - Open
	Park Brake		Park Brake Release		Hydraulic Oil Level

	Up/Down Arrow		Down/Lower		Up/Raise
	No Smoking		Moving Parts		Manual Operation
	Pinch Point		Step		Hot Surface
	Hydraulic Fluid Penetration		Lift Arm		Tractor
	Engage		Disengage		PTO
	Ground Speed		Fast		Slow
<b>H</b>	High	<b>L</b>	Low	<b>F</b>	Forward
<b>R</b>	Reverse	<b>N</b>	Neutral		Warning Danger Caution

Read and understand this manual and all safety signs before operating and maintaining. Review the safety instructions and precautions annually.

**TAKE NOTE! THIS SAFETY ALERT SYMBOL FOUND THROUGHOUT THIS MANUAL IS USED TO CALL YOUR ATTENTION TO INSTRUCTIONS INVOLVING YOUR PERSONAL SAFETY AND THE SAFETY OF OTHERS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN INJURY OR DEATH.**



## SAFETY SIGNAL WORDS



Note the use of the signal words DANGER, WARNING and CAUTION with the safety messages. The appropriate signal word for each has been selected using the following guidelines:

**DANGER:** Red. Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations typically for machine components which, for functional purposes, cannot be guarded.



**WARNING:** Orange. Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury, and includes hazards that are exposed when guards are removed. It may also be used to alert against unsafe practices.



**CAUTION:** Yellow. Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.




**IMPORTANT:** Blue. Indicates procedures which should be followed to avoid damage to the machine.



**REMEMBER:** If Safety Decals\*\* have been damaged, removed, become illegible or parts replaced without decals, new decals must be applied. New decals are available from your authorized distributor.

This is a list of decals located on the Spray Star 3180. Part number, description and location will help in reordering a decals.

- |   |        |                         |
|---|--------|-------------------------|
| A | 15-463 | Decal Spray Pump        |
|   | 25-375 | Decal, 94 dBA           |
| B | 25-277 | Decal, Battery Warning  |
| C | 25-286 | Decal, Pinch Point      |
| D | 25-298 | Decal, Warning Hot      |
| E | 25-321 | Decal, Diesel Fuel Only |
| F | 20-545 | Decal, Dash Panel       |
| G | 30-157 | Decal, Control Panel    |



## SAFE PRACTICES

1. It is your responsibility to read this manual and all publications associated with this machine.
2. Never allow anyone to operate or service the machine or its optional equipment without proper training and instructions. Never allow minors to operate any equipment.
3. Learn the proper use of the machine, the location and purpose of all the controls and gauges before you operate the equipment. Working with unfamiliar equipment can lead to accidents.
4. Wear all the necessary protective clothing and personal safety devices to protect your head, eyes, ears, hands and feet. Operate the machine only in daylight or in good artificial light.
5. Inspect the area where the equipment will be used. Pick up all debris you can find before operating. Beware of overhead obstructions and underground obstacles. Stay alert for hidden hazards.
6. Never operate equipment that is not in perfect working order or without decals, guards, shields, or other protective devices in place.
7. Never disconnect or bypass any switch.
8. Carbon monoxide in the exhaust fumes can be fatal when inhaled, never operate a machine without proper ventilation.
9. Fuel is highly flammable, handle with care.
10. Keep engine clean. Allow the engine to cool before storing and always remove the ignition key.
11. Disengage all drives and set park brake before starting the engine.
12. Never use your hands to search for oil leaks. Hydraulic fluid under pressure can penetrate the skin and cause serious injury.
13. This machine demands your attention. To prevent loss of control or tipping of the vehicle:
  - A. Use extra caution in backing up the vehicle. Ensure area is clear.
  - B. Do not stop or start suddenly on any slope.
  - C. Reduce speed on slopes and in sharp turns. Use caution when changing directions on slopes.
  - D. Stay alert for holes in the terrain and other hidden hazards.
14. Before leaving operator's position:
  - A. Disengage all drives.
  - B. Set park brake.
  - C. Shut engine off and remove the ignition key.
  - D. If engine has to run to perform any maintenance keep hands, feet, clothing and all other parts of body away from moving parts.
15. Keep hands, feet and clothing away from moving parts. Wait for all movement to stop before you clean, adjust or service the machine.
16. Keep the area of operation clear of all bystanders.
17. Stop engine before making repairs/adjustments or checking/adding oil to the crankcase.
18. Use parts and materials supplied by **SMITHCO** only. Do not modify any function or part.
19. Use caution when booms are down as they extend out beyond the center line of the machine.
20. The tank is a confined space, take precaution.

***These machines are intended for professional maintenance on golf courses, sports turf, and any other area maintained turf and related trails, paths and lots. No guaranty as to the suitability for any task is expressed or implied.***





Persons engaged in the handling, preparation or application of chemicals must follow accepted practices to insure the safety of themselves and others,

1. **WEAR** protective clothing including: gloves, hat, respirator, eye protection and skin covering suitable for protection from chemicals being used.
2. **BATHE** thoroughly after any exposure to chemicals, giving particular attention to eyes, nose, ears and mouth.
3. **CLEAN** equipment and materials in accordance with employer, municipal and state regulations. Use only approved areas and drains.
4. **DISPOSE** of chemicals and rinse solutions by approved and legal means.
5. **PROVIDE** methods and materials for operators to wash eyes and hands immediately during the spraying process.
6. **PROVIDE** methods and materials for control, safe dilution and neutralization of chemical spills during preparation, spraying, transporting and cleanup.
7. Always check and follow the directions and safety warnings of the chemicals to be used.
8. Secure the discharge lines before starting the pump. An unsecured discharge line may whip.
9. Periodically inspect the pump and the system components.
10. Check hoses for weak or worn condition before each use. Make certain that all connections are tight and secure.
11. Do not operate unit with leaks, frayed, kinked hoses or tubing. Repair or replace immediately.
12. Use only pipe, hose and fittings rated for maximum pressure or pressure at which pressure relief valve is set at. When replacing pipe, hose or fittings, use new product.
13. Do not operate an engine in an enclosed area. Be sure the area is well ventilated.
14. Do not use these pumps for pumping water or other liquids for human or animal consumption.
15. **Do not pump flammable or explosive fluids such as gasoline, fuel oil, kerosene, etc.**  
**Do not use in explosive atmospheres. The pump should be used only with liquids compatible with the pump component materials.**
16. Be sure all exposed moving parts are guarded and that all coupling devices are securely attached before applying power.
17. Before servicing, disconnect all power, make sure all pressure in the system is relieved, drain all liquids from the system and flush.
18. Protect pump from freezing conditions by draining liquid and pumping rust inhibiting antifreeze solution through the system, coating the pump interior.
19. **TRANSPORT** - Machine **must be stopped** to raise or lower booms. Because of cam system, if booms are raised in transit they can fall forward or backward when coming to a stop or while traveling on uneven terrain.



Read and understand this manual and all safety signs before operating and maintaining. Review the safety instructions and precautions annually.

**TAKE NOTE! THIS SAFETY ALERT SYMBOL FOUND THROUGHOUT THIS MANUAL IS USED TO CALL YOUR ATTENTION TO INSTRUCTIONS INVOLVING YOUR PERSONAL SAFETY AND THE SAFETY OF OTHERS. FAILURE TO FOLLOW THESE INSTRUCTIONS CAN RESULT IN INJURY OR DEATH.**

## SPECIFICATIONS

### WEIGHTS AND DIMENSIONS

Length	128" (325 cm)
Width	72" (183 cm)
Height w/ ROPS	84" (213 cm)
Height w/ Booms Folded	136" (345 cm)
Wheel Base	68" (173 cm)
Weight Empty	2340 lbs (1061 kg)
Weight Full	4950 lbs (2245 kg)

### SOUND LEVEL (DBA)

At ear level	88.4 dBA
At 30 ft. (9.14 m)	77 dBA

### ENGINE

Make	Kubota
Model#	V1505
Type / Spec#	1G994-0000
Horsepower	35.5 hp (26.6 kW)
Fuel (EMISSIONS)	No.1-D or No. 2-D, S500: Low Sulfur Diesel (LSD) less than 500 ppm or 0.05 wt. % No1-D or No.2-D, S15: Ultra Low Sulfur Diesel (ULSD) less than 15 ppm or 0.0015 wt. %
Cooling System	Liquid Cooled
Lubrication System	Full Pressure
Alternator	15 Amp

### WHEELS & TIRE

Front: Two 20 x 11.00 x 10 Turf; 20 psi (1.4 bar)  
Rear: Two 29 x 14.00 x 15 Multi-Trac; 30 psi (2.0 bar)

### SPEED

Infinitely Variable 0-10 m.p.h. (0-18 kph)

### BATTERY

	Automotive type 24F - 12 volt
BCI Group	Size 24
Cold Cranking Amps	900 minimum
Ground Terminal Polarity	Negative (-)
Maximum Length	10.25" (26 cm)
Maximum Width	6.88" (17 cm)
Maximum Height	10" (25 cm)

### FLUID CAPACITY

Crankcase Oil	See Engine Manual
Fuel	7 gallon (26.5 liters)
Hydraulic Fluid	10 gallon (37.8 liters)
Grade of Hydraulic Fluid	SAE 10W-40 API Service SJ or higher Motor Oil
Radiator	1.06 gallons

## OPTIONAL EQUIPMENT

15-618	Water Meter Kit	30-009	Manual Hose Reel
17-585	18' HD Super Boom	30-010	Electric Hose Reel
17-580	20' HD Super Boom	30-004	Foam Marker
30-006	Fresh Water Tank	15-835	Tank Rinse System
30-007	Chemical Cleanload Safe Fill	15-850	Sunshade Canopy
31-006	All Weather Top		
17-590	Lazer-Beam Auto Boom for HD Booms		




The Spray Star 3180 arrives from **Smithco** setup and ready for service. Depending on freight conditions battery installed. The spray system is normally shipped attached to the 3180 Prime Mover. If a spray system is to be fitted to a Prime Mover by a dealer or factory, assemble and attach the components in accordance with the parts drawings in the *Spray Star 3180 Parts/Service Manual*.

1. Check the tire pressure. The front tires are 20 psi (1.4 bar) and rear tires are 30 psi (2.0 bar).
2. Battery is located under seat. This is a negative grounding system.

**⚠ WARNING**

**Connecting battery cables to the wrong post could result in personal injury and/or damage to the electrical system. Make sure battery and cables do not interfere or rub on any moving part.**

**Connect red positive (+) cable (A) to battery first. When disconnecting remove black negative (-) cable (B) first.**



3. Check hydraulic fluid level in tank located under the seat. Remove cap and add SAE 10W-40 API Service SJ or higher motor oil if necessary. Fluid level should be about 2-2 1/2" (5-6.4 cm) from the top of the tank when cold. DO NOT OVERFILL.
4. Fill fuel tank, located on right side, with No. 2 diesel

**⚠ DANGER**

**Fuel is flammable, caution must be used when storing or handling it. Do not fill fuel tank while engine is running or an enclosed area, fumes are explosive and dangerous to inhale. DO NOT SMOKE while filling the fuel tank. DO NOT OVERFILL**

5. Machine should be greased before starting, refer to *Spray Star 3180 Parts/Service Manual* for location.
6. Attach the Spray Boom and any other Optional Equipment to the Prime Mover, in accordance with instructions in the *Spray Star 3180 Parts/Service Manual*. The nozzles must be the correct distance above the turf as described in *Turf Spraying Guide*. The spray boom must operate properly and the outer sections must break away safely if an object is struck by them, they must then return to normal operation position.
7. Be sure to double check boom heights, nozzle spacing and displacement before spraying.
8. Machine is shipped with windshield washer fluid in to prevent freezing. Flush system completely with clear water. Fill tank with water and retighten the four bolts used to hold the tank in place.
9. Read operating instructions before starting.

**⚠ IMPORTANT**

**Never allow pump to run dry! The valve on the suction side of the pump (between the pump and tank) must be fully open whenever the pump is operated.**

FUEL

**CHECK EMISSION REGULATIONS OF YOUR AREA**

With Emission control now in effect diesel fuel specification type and sulfur content % (ppm) used must be in compliant with all applicable emission regulations for the area in which the engine is operated.

Use of diesel fuel with sulfur content less than 0.10% (1000 ppm) is strongly recommended.

If high sulfur fuel is used, change oil and oil filters twice as often.



DO NOT USE Fuels that have sulfur content greater than 1.0% (10000 ppm).

Diesel fuels specified in EN 590 or ASTM D975 are recommended.


Since KUBOTA diesel engines of less than 56kW (75 hp) utilize EPA Tire 4 and Interim Tier 4 Standards, the use of low sulfur fuel or ultra low sulfur fuel is mandatory for these engines, when operated in US EPA regulated areas. Therefore, use No. 2-D or Sulfur Diesel Fuel with a Positive toe No. 2-D for ambient temperatures below -10°C (14° F).

**SAFETY SIGNAL WORDS**

## CONTROLS & INSTRUMENTS



- A. Hour Meter - The hour meter indicates hours of machine operation. It operates only when the ignition switch is on.
- B. Glow Plug - When ignition is turned on, glow plug lights when ready to start.
- C. Water Temperature Light - Temperature light will come on when the engine starts to overheat.
- D. Ignition Switch - The ignition switch has three positions: Off - Run - Start.
- E. Tilt Steering - Hold lever down and adjust steering wheel to desired position and release lever.
- F. Oil Light - The oil light should come on when the ignition is on without the engine running and go out when the engine is running. The oil light will light when the oil pressure is low. If oil light should come on, shut engine off immediately and find the cause.
- G. Speedometer - The Speedometer indicates ground speed of the vehicle in miles per hour and kilometers per hour.
- H. Lights - This rocker switch turns lights on by pushing on the top and off by pushing on the bottom.
- I. Ground Speed (Cruise) Control - This rocker switch initiates cruise control by pushing on the top and turning it off by pushing on the bottom. Works with ground Speed Control Foot switch.
- J. Buzzer - The buzzer sounds if the pump is running dry.
- K. Spray Pump - This rocker switch turns the spray pump on by pushing on the top and off by pushing on the bottom.
- L. Left Boom Switch - This rocker switch lifts and lowers the left boom.
- M. Right Boom Switch - This rocker switch lifts and lowers the right boom.
- N. Hand Throttle - The hand throttle is used to regulate engine speed.
- O. Cup Holder - Holds standard cup.
- P. Spray Boss Control - Engages and disengages speed boss. Forward is engage and all the way back is disengage. When the lever is engaged it sets a stop for the accelerator. The accelerator pedal must be used to maintain this speed. To adjust speed use the knob on the end of the lever, counter clockwise increases speed and clockwise decreases speed. Disengage the lever and you will have full accelerator pedal range.
- Q. Park Brake Toggle Switch - This toggle switch will engage park brake. Lift toggle cover and move switch forward. **DO NOT ENGAGE WHILE IN MOTION.**



- R. Ground Speed (Cruise) Control Foot Switch - When rocker switch is turned on and desired speed is obtained, push foot speed control switch to set cruise. (see below).
- S. Master Boom Switch - located on the left floorboard is used to override the master switch on the computer console of the spray systems. By pushing down it will turn on/off the booms. **For the 440 System only** the Master Switch on the computer **must be off** for the master boom control switch to work.
- T. Accelerator Pedal - This pedal controls ground speed. Press pedal to increase speed. Varying the amount of movement of the pedal will vary the ground speed.
- U. Reverse Pedal - This pedal controls reverse. Press pedal to move machine in reverse.

## GROUND SPEED CONTROL


The ground speed control does not work the same as an automotive type cruise. The ground speed control is located on the center floorboard and is used to lock forward speed.

### TO ENGAGE:

1. Flip rocker switch 'On' (green light).
2. Obtain desired speed with foot pedal.
3. Step on foot switch to lock speed.
4. Push foot switch again to disengage.

### CAUTION

**To avoid abrupt stop, place foot on traction pedal before disengaging speed control.**




## TOWING

When it is necessary to move the Spray Star 3180 without the engine running, there are 2 things that need to be done. First, the bypass valve built into hydrostatic pump must be "open" by turning it 1/4 turn to open. The valve is located on the back side of the pump. An "open" valve allows fluid to pass through the wheels freely. When normal driven operation is desired, valve should be "closed" by turning it clockwise. Failure to "close" the valve with engine running means no power to wheels. Secondly, the hand brake needs to be manually released. The hand brake is located under the engine. To manually release the brake you must loosen the locknut and screw in the stem to the bottom. Tighten the lock nut and pump handle until hard.

## MANUAL BRAKE HAND PUMP MANIFOLD

The hand brake is located under the engine. The hand brake is connected to the seat switch and automatically engages when operator gets up from the seat. So when machine is not being driven, the machine is locked down. If engine is not running or you are towing the machine you will have to manually release the brake. **To manually release the brake** you must loosen the locknut and screw in the stem to the bottom. Tighten the lock nut and pump handle until hard.



**Run machine at half-throttle minimum, prior to operating traction pedal. This will ensure proper brake release.**

## OPERATION

Before operating the Spray Star 3180, become familiar with all controls and functions. Also complete all maintenance requirements and read all safety warnings. Knowing the Spray Star 3180 thoroughly, how it operates, and by doing the prescribed maintenance steps, you can expect trouble free operation for years to come.

### SAFETY

Operator needs to always be the concern of an operator of a moving vehicle or any machine with moving parts.


1. Keep all shields and guards in place.
2. Keep the parking brake engaged any time the operator is away from the vehicle or whenever service is performed.
3. Always wear the necessary protective clothing and equipment.
4. Turn engine off when refueling or performing maintenance not specifically requiring engine power.

### DAILY CHECKLIST

1. Check the engine oil level. Add as needed. **DO NOT OVERFILL**. Refer to engine owner's manual for oil grade and procedure.
2. Tire pressure should be 20 psi (1.4 bar) on front and 30 psi (2.0 bar) on back.
3. Inspect the electrical system and battery cables for loose connections or frayed wiring. Replace any faulty equipment or tighten if loose.
4. Check hardware for loose or missing nuts, bolts, screws, etc., and tighten or replace as needed.
5. Inspect hydraulic lines for damage or leaks. Never use hands to inspect for leaks.
6. Check the hydraulic fluid level. The hydraulic fluid tank is located under the seat. The fluid level should be 2"-2½" (5 - 6.4 cm) from the top of the tank when cold. Use only SAE 10W-40 API Service SJ or higher Motor Oil.
7. Inspect the steering, throttle and shift linkages for good hookups and clear travel.
8. Check controls for smooth, proper working operation. Lubricate as needed.
9. Check anti-vibration mounts on engine frame.

### STARTING THE ENGINE

1. Make sure both fuel flow valves are 'On'. They are located on the fuel tank.
2. The ignition switch is located on the dashboard. Insert the key (A) and turn clockwise to (B). When glow plug light goes off Turn key to (C) until the engine starts. Release the key and it will return to the run position (B).
3. Allow engine to idle and warm up before selecting direction of travel.



### STOPPING THE ENGINE

#### **⚠ IMPORTANT**

**If the engine has been running under high power, let it run at slow idle speed a few minutes to cool the engine down, before turning the ignition switch to the OFF position.**

1. Disengage spray pump.
2. Move the throttle lever to "slow" and turn ignition key to the "off" position.
3. Remove the ignition key and engage the park brake.

#### **⚠ CAUTION**

**Never leave the vehicle unattended with the engine running. Always bring the vehicle to a complete stop, engage park brake, turn key off and remove key.**

PARTS MANUALS AVAILABLE ONLINE AT [smithco.com](http://smithco.com)

## IMPORTANT

**Run machine at half-throttle minimum, prior to operating traction pedal. This will ensure proper brake release.**

Before using the Spray Star, the operator and spray technician must familiarize themselves with all of the information on chemical spraying contained in the *Turf Spray Guide*.

All testing and calibrating of sprayers is to be done with water, not chemicals. This insures the safety to all involved in performing the calibration operation. Only after all calibration procedures are completed should chemical be added to the sprayer.

### HILLSIDE OPERATION

Do NOT stop or start suddenly on any slope. Be especially cautious when changing direction. Do NOT operate on slopes greater than 10°.

### BATTERY

Batteries normally produce explosive gases which can cause personal injury. Do not allow flames, sparks or any ignited object to come near the battery. When charging or working near battery, always shield your eyes and always provide proper ventilation.

Battery cable should be disconnected before using "Fast Charge".

Charge battery at 15 amps for 10 minutes or 7 amps for 30 minutes. Do not exceed the recommended charging rate. If electrolyte starts boiling over, decrease charging.

Always remove grounded (-) battery clamp first and replace it last. Avoid hazards by:

1. Filling batteries in well-ventilated areas.
2. Wear eye protection and rubber gloves.
3. Avoid breathing fumes when electrolyte is added.
4. Avoid spilling or dripping electrolyte.

## WARNING

**Battery Electrolyte is an acidic solution and should be handled with care. If electrolyte is splashed on any part of your body, flush all contact areas immediately with liberal amounts of water. Get medical attention immediately.**

### JUMP STARTING


## WARNING

**Use of booster battery and jumper cables. Particular care should be used when connecting a booster battery. Use proper polarity in order to prevent sparks.**

To jump start (negative grounded battery):

1. Shield eyes.
2. Connect ends of one cable to positive (+) terminals of each battery, first (A) then (B).
3. Connect one end of other cable to negative (-) terminal of "good" battery (C).
4. Connect other end of cable (D) to engine block on unit being started (NOT to negative (-) terminal of battery)

To prevent damage to other electrical components on unit being started, make certain that engine is at idle speed before disconnecting jumper cables.



## OPERATION (CONTINUED)

### SPRAYER VALVE SETTINGS AND SPRAY TANK AGITATION

The 3-way valve on the suction side of the pump, between the tank and the pump must be open before pump is engaged. Close this valve only when necessary to clean the filter with spray material in the spray tank.

There is one manual flow control valve on the discharge side of the spray system. This valve controls the agitator. This valve may be opened as much as necessary to provide hydraulic agitation through the quadrajet agitator in the tank bottom. This valve may be partially closed to prevent or reduce foam buildup from the spray materials inside the tank. When the liquid level in the spray tank reaches a certain level (usually 1-25 gallons (3.8-95 Liters) depending on terrain and other conditions) it may be necessary to close the valve in the agitator line in order to prevent loss of suction prime.

If your Spray Star is fitted with a hose reel, there is a second ball valve on the discharge system to supply material to the hose reel.

The Quadrajet agitation system operates with four venturi jets in the tank bottom. These jets have replaceable orifice discs which discharge the following amounts of spray material.

Nozzle Diameter	Input to Agitator in gpm	Input to Agitator in L/min	Agitator Pressure in psi	Agitator Pressure in bar	Agitator Output in gpm	Agitator Output in L/min
1/8"	1.9	7.2	25	1.7	6.3	23.8
1/8"	2.7	10.2	50	3.4	10.0	37.9
1/8"	3.8	14.4	100	6.9	15.0	56.8
5/32"	2.8	10.6	25	1.7	7.6	28.8
5/32"	4.2	15.9	50	3.4	12.2	46.2
5/32"	5.5	20.8	100	6.9	17.5	66.2
3/16"	3.6	13.6	25	1.7	9.1	34.4
3/16"	5.6	21.2	50	33.4	14.3	54.1
3/16"	7.9	29.9	100	6.9	18.7	70.8

You can change orifice disc sizes to enhance spray system performance. Smaller discs reduce amount of agitation (desirable in some foaming materials) and make more dischargeable liquid available for nozzles. Larger (or none) discs increase amount of agitation and make less dischargeable liquid available for nozzles.

## ENVIZIO PRO II DO'S AND DON'TS

### DO'S AND DON'TS

- Do** have the serial number and firmware revision available when calling for technical assistance. It is best if the user is in the machine and in front of the field computer when calling for support.
- Do** review the manual in its entirety before operating the field computer.
- Do** turn machine on prior to starting Envizio Pro II. Voltage spikes can cause damage to computer.
- Don't** let water on or near Envizio Pro II Computer.
- Don't** turn the field computer off without properly closing any open jobs and powering down the computer. If the field computer loses power during a job, information within the job files may be lost and the associated files may become corrupt.
- Do** power down Envizio prior to shutting off machine.
- Don't** use sharp objects or harsh chemicals on the field computer touch screen as they may damage the display. Console Features
- Do** remove Envizio Pro II during cold weather. Cold weather will cause the battery to drain.


Envizio Pro II comes with a Quick Reference Guide and an Installation & Operation Manual. Please read these manuals before operation. Manuals can be downloaded off the internet at [www.ravenprecision.com](http://www.ravenprecision.com) and off the [www.smithco.com](http://www.smithco.com) website under Parts and Technical Information.

PARTS MANUALS AVAILABLE ONLINE AT [smithco.com](http://smithco.com)





# ENVIZIO PRO II - SHARPSHOOTER - RATE SYNC FEATURES



## INITIAL SETUP

To Begin a Job & Create a Spray Zone  
**Turn Sharpshooter w/RateSync On**  
**Press Auto/Manual button to Auto**  
**PSI is preset. Use arrow buttons to increase/decrease**

# INITIAL SETUP

**1. Turn Raven Envizio Pro Controller On**

Hold Blue Switch until screen lights up.  
Wait until Home Screen Appears (see right)



**2. Check to Insure GPS Icon is Green**

Touch the Green Arrow to enter Job Menu where you can Start a New Job



**3. New Job Menu**

Insure Arrow on Tractor is Forward  
Touch Icon to Correct if Needed  
Touch the Blue "Job" Box to Start a New Job

**4. Start a New Job Screen.**

Touch the Yellow New Job Box  
(This will bring up the Keyboard Screen)



**5. Name the Job**

This can be as elaborate or as simple as you like.

Examples: South Course Fairway No. 4  
Or SF4

Touch the Green "Check" Circle  
Touch the Blue "Pattern" Box  
(This Will Bring Up Your Next Pass Options)

Select "Last



Pass" A - B




6. Touch the “AccuBoom” Blue Box



7. Touch to Check “Use Spray Zone Map”



8. Touch the Yellow New “Field Boundary Map”




9. This will bring up the Keyboard Screen Again, Name the New Field Boundary Map; it’s best to use the same name as the New Job file. Touch the Green “Check” Circle

This will return you to the Job “As Applied” Screen



10. Creating a Field Boundary

Drive to the area where you want to start your Spray Zone. Press the Green “Menu” Box in the Lower


Right Corner  To Bring Up the Tools Menu Along the Right Side

Press the Black “Boundary Tools” Box 

Touch the Black “Record Field Boundary” Box 

# INITIAL SET UP

11. Select One of the Options Below to Create the Field Boundary



12. This will Enable the On screen Mapping Tools




13. Screen with Field Boundary Tools on Screen



14. Drive the Outline of the Area. You will see the Yellow Line that will be the boundary of the Field Boundary located at your selection point. Press the Black "Pause" Box at any time to Maneuver the Sprayer to create a Square Corner




15. Press the Black "Stop" Box when at the End of the Area You Want to Map. The Envizio Pro will Draw a Straight Line to Point where Recording Began to Close the Spray Zone



16. Press the Green "Menu" Box, then the Green "Check" Box



17. The Spray/No Spray Boundary Line will then be represented in Blue and Areas with Application Previously Applied will be Represented in Green; Your Next Pass A B Line is Represented in Red



# SHARPSHOOTER -RATE SYNC

SharpShooter with Rate Sync (SSRS Display)




Figure 1




Figure 2

The SSRS Display [Figure 1] has five buttons to navigate and control the system. A screen on the SSRS Display interface provides immediate information and easy access to the menu items.

Connections on the back of the SSRS Display [Figure 2] include the main connection port, a gps connection port and diagnostic connection port.

**Power Button** - Press the power button to turn on the SSRS Display. The system defaults to manual mode each time it is powered up.

With the SSRS Display turned OFF, the sprayer will only operate as a conventional rate controller. The Nozzle Solenoids work as an electric On/Off drip check and work with the boom section On/Off switches.

**NOTE: Spraying in the OFF mode will require selecting different tips.**

**Menu Button** - The menu button is used to enter and exit the menu list. Press menu button to enter the menu list pages, use the increase/decrease buttons to navigate the menu list highlighting the desired field. Press the enter button to exit menu structure, highlight the exit menu line and press the menu button.

**Auto/Manual Button** - Manual mode is the default mode at power up. Manual mode will pulse nozzle valves at the duty cycle percentage selected by the increase/decrease buttons. The Manual mode is used in the event that the SSRS Display fails to automatically control pressure. It is not necessary to change tips.

Manual Mode can also be used to close all nozzle valves. By toggling down to 10% duty cycle, then pressing decrease once more. This will close all solenoids and the diagnostic readout will show "OFF".

**NOTE: In the Manual mode the increase/decrease buttons act like an electronic rotary nozzle body with an "infinite" number of tips that can be selected by the operator.**


Automatic mode is the standard operating mode for the SharpShooter with Rate Sync system. In Auto mode the SSRS Display will automatically work to maintain an operator - set target pressure. It does this by pulsing the nozzle valves at a duty cycle percentage controlled by the target pressure. Activate the automatic pressure control by pressing the auto/manual button. The LED light behind auto/manual button will illuminate when auto mode is selected.

### Increase/Decrease Buttons -

1. Manually select duty cycle percentage, or effective tips size in Manual mode, or
2. Set target pressure in Auto mode letting the SSRS Display determine the duty cycle, or in other terms, the “effective tip” size required.
3. Navigate up and down in menu structure.

**Display Screen** - Is a real time readout of the SharpShooter with Rate Sync system operation.

Actual pressure, effective tip size, and duty cycle are displayed in the Manual mode. Actual pressure, target pressure and duty cycle appear in the AUTO mode. A diagnostics readout area appears in both modes.



**Figure 3**

**Indicator Lights and Sounds** - The SSRS Display indicator lights are located behind the Power button and Auto/Manual button.

When the SSRS Display is powered on, the indicator light behind the power button (Item 1) [Figure 3] will appear constant. This signals a properly operating system.

The indicator light behind the Auto/Manual button (Item 2) will be off when in manual mode (also read out in center of screen). When Auto mode (Item 3) [Figure 3] is selected, the indicator light will turn on and screen readout will change to show target pressure.

The SSRS Display includes audible and visual alarms. The audible alarms are an accessible menu item. Visual alarms include a readout area in the lower right hand portion of the screen and a flashing light behind the power button.

**Please read RateSync manual for detailed information.**

## SPRAY OPERATION

One of the most common causes for faulty-pump performance is corrosion inside the pump. Flush the pump and entire system with a solution that will chemically neutralize the liquid pumped. Mix according to manufacturer's directions. This will dissolve most residue remaining in the pump, leaving the inside of the pump clean for the next use.

### TO PREVENT CORROSION

After cleaning the pump as directed, flush it with a permanent type automobile antifreeze (Prestone, Zerex, etc.) containing a rust inhibitor. Use a 50% solution that is, half antifreeze and half water. Then coat the interior of the pump with a substance which will prevent corrosion such as Fluid Film or WD40. If unit will not be used for an extended period of time, disconnect hoses into and out of the pump, seal openings to the pump with caps or tape. Dispose of fluids according to all federal, state and local regulations.



### IMPORTANT

**All chemicals and chemical residue must be removed after each use. Dispose of fluids and residue according to all federal, state and local regulations.**

### SPRAYER CLEANING

Empty tank and clean unit thoroughly after each use following these instructions:

1. Turn off 3-way valve and rinse inside of tank thoroughly with clean water, remove cap from valve to drain.
2. Fill tank ten percent full with clean water, Turn 3-way valve on and start pump and discharge water through spray hose or spray boom (with nozzles removed), until empty.
3. Turn off 3-way valve again and rinse tank interior thoroughly. Remove cap from 3-way valve to drain.
4. Rinse exterior of sprayer thoroughly with clean water.
5. This sprayer is equipped with a self cleaning strainer. The strainer uses the excess pump flow to bypass clogging particles back to the spray tank. There is a gap between the tapered inner cylinder and the screen face that causes the inlet fluid to flow at a high velocity past the screen face providing a continuous wash down of particles. For this wash down to occur a minimum of +GPM/23 l/min is required through the bypass line.

### MANUAL HOSE REEL

Located at the back of the Spray Star on top of the tank. Open the ball valve located near the manifold valve to allow fluid to flow into the hose reel. Place the lockout pin in the unlocked position by pulling and turning it half a turn, this will allow you to pull out additional hose or to use the handle and wind up the hose. To prevent movement during transport or storage place the lockout pin in the locked position.

### ELECTRIC HOSE REEL

Located at the back of the Spray Star on top of the tank. Open the ball valve located near the manifold valve to allow fluid to flow into the hose reel. To unwind hose just pull on the hose to get the desired amount. To wind up the hose make sure the toggle switch is in the ON position, push the momentary push button switch until you have reeled in the amount of hose desire. Turn off the safety switch when not in use.

### FOAM MARKER

Located to the right of the control panel. Use lever on compressor to designate which boom is to be used to dispense foam. Use dial located on the foamer to adjust pressure for the amount of foam that will be dispensed. Switch on compressor also turns foamer on or off.



## SPRAYING INTRODUCTION

This section is intended to offer practical guidelines for the distribution of liquid chemicals over an area of turf grass such as golf courses, park land, school grounds and lawns. SMITHCO makes no representation as to the suitability of any technique or product for any particular situation. This section is suitable for self-propelled spray vehicles or sprayers mounted onto vehicles.

Boom Spraying is the most effective, accurate and efficient method of applying chemicals to large turf areas. It may be done by means of:

- A dedicated spray vehicle
- A sprayer mounted upon a utility vehicle

Sprayers are typically equipped with wide spray booms. Generally these booms are between 15 feet (4.5 m) and 20 feet (6 m) in width. They are divided into three sections, with hinges that permit the long outer sections to automatically move out of the way and reset if an obstacle such as a tree or fence is in your path.

To minimize the chance for missed areas or double application use a device to mark the outside boundaries of each spray swath. Foam markers and dye markers are advisable.

## PROCEDURE TO RE-CALIBRATE FLOWMETER

1. Enter a Meter Cal number of 10 in Meter Cal Button
2. Enter a Total Volume of Calibrating the Pressure Gauge in Total Volume button
3. Switch Off all booms.
4. Remove a boom hose and place in calibrated 5 gallon container
5. Switch on appropriate boom switch and master switch. Pump exactly 10 gallons.
6. Readout in Total Volume is the new Meter Cal Number. Should be within 3% of number stamped on flowmeter.
7. Repeat the procedure several times to ensure accuracy.
8. To verify calibration, fill applicator tank with predetermined amount of measured liquid. **DO NOT RELAY ON GRADUATION NUMBERS ON MOLDED TANK.** Empty tank under normal operation conditions. If the number under total volume is different from the predetermined amount of measure by more than 3% complete calculation in back of book.
9. Enter corrected Meter Cal before resuming application.

## TURF MANAGEMENT

Turf management chemicals are made for four general purposes:

1. **Fungicides:** Prevent or cure fungus on turf grass. They are made in 2 general types:
  - Systemic - Chemicals enter the plant system and protect or cure it of, fungus.
  - Contact - Kills fungus with which it comes into contact.
2. **Insecticides:** Eliminate damaging insects and worms (such as grubs, beetles, ants, etc.)
3. **Herbicides:** Control and eliminate undesirable weeds and grass from turf areas and non-turf areas such as bunkers, trails, fences, etc.
4. **Nutrients & Fertilizer:** Promote growth, beauty and color in turf grass.

Some materials have to be applied so that they get into the soil below the plant leaves, This is called "*soil application*". In order to do this, they are best applied with a *large volume of water*. They are often then *watered-in* using the irrigation system. This type of chemical material includes systemic chemicals and chemicals designed to destroy pests which live in the thatch and the soil.

Other materials must be applied to reach a problem that is present on the plant leaves. This is called "*Foliar Application*" and requires a *lower volume* of water. Instead of irrigation water, these materials are further activated by dry air and sunshine. They include contact fungicide and many herbicides.

The user of sprayers and chemicals must follow the directions provided with the spray material. It is the only way to insure safe and effective results. It provides information on how much chemical and how much water is to be applied to the area to be sprayed.

Though there are many types and sizes of nozzles, two specific types have proven most successful in turf grass management.

- The first type is **target-directed**. It sprays material in a direct line downwards to the target turf grass. These are flat fan nozzles, commonly referred to as TeeJet nozzles. They are available in a wide variety of sizes for any required discharge volume rate. They are the best for many contact or foliar applied pesticides. They are spaced either 10" (25 cm) or 20" (51 cm) apart and overlap one another by about  $\frac{1}{3}$ .
- The second type useful in turf management are **broadcast** type nozzles. They are commonly referred to as raindrop or floodjet nozzles. They spray a hollow-cone shaped pattern of much larger droplets which fall quickly to the turf under their own weight. They are best for systemic pesticides or any material requiring a large volume of water for soil application. The larger droplets are not as subject to drift from wind and are a safer, more environmentally friendly choice in many situations.

## HOSE & HANDGUN SPRAYING

A handgun (hand-nozzle or hand-lance) is used to control and direct the spray pattern to the ground, shrub or tree. They must be constructed of long lasting and noncorrosive materials such as brass, stainless or aluminum. The handgun fits to a hose of any length from the sprayer allowing operator mobility. The hose should be as short as possible while still permitting operator mobility.

Liquid loses pressure due to friction as it travels through the hose, 1-3 psi (0.07-0.21 bar) for each foot (30 cm) of hose. For most operations  $\frac{1}{2}$ " (1.25 cm) inside diameter hose is adequate. Trees over 40 ft (12 m) high require  $\frac{3}{4}$ " (2 cm) inside diameter hose and a sprayer pump capable of delivering a volume of at least 20 gpm (75 lpm) and a pressure of at least 400 psi (28 bar).

## TROUBLE SHOOTING NOZZLE VALVES

Plugged nozzle valves can be classified in two categories:

Plunger blockage.

Plunger stuck.

Plunger blockage results when larger debris catches between the orifice and plunger seal. This is the smallest flow passage within the nozzle valve.

Stuck plungers result when smaller debris collects around the barrel of the plunger and binds the plunger in place.

Symptoms of a blocked or stuck plunger are:

Constant spray.

Dripping when nozzle is shut off.

### ⚠ IMPORTANT

*Pinched or split o-rings will also cause nozzles to drip.*

### ⚠ IMPORTANT


*Operating a plugged nozzle valve for extended periods may result in nozzle valve coil failure. Clean plugged nozzle valves immediately.*

### ⚠ IMPORTANT

*If plugged nozzles are a frequent problem in a particular boom section, inspect the machines boom filter screens for plugged or damaged screens. An 80 mesh screen is recommended to prevent nozzles from plugging. Check the mesh size of the strainers and replace if they are too coarse.*

Nozzle valve component identification.

- |    |            |            |
|----|------------|------------|
| 1. | O-ring     | 30-168-18P |
| 2. | O-ring     | 30-168-20P |
| 3. | Valve Body | 30-168-26P |
| 4. | Flynut     | 30-168-25P |
| 5. | Plunger    | 30-168-17P |
| 6. | O-ring     | 30-168-19P |
| 7. | Coil       | 30-168-21P |



The nozzle valve assembly (30-168-05P) screws into the nozzle bodies replacing the standard diaphragm check valve.

- |    |                                |            |
|----|--------------------------------|------------|
| 1. | Complete Nozzle Valve Assembly | 30-168-05P |
|----|--------------------------------|------------|



# TROUBLE SHOOTING NOZZLE VALVES


## NOZZLE CLEANING

### **⚠ WARNING**

Before removal or installation of nozzle valves make sure pressure has been removed from the sprayer lines.

Remove the O-ring (Item 1), O-ring (Item 2), valve body (Item 3), flynut (Item 4), plunger (Item 5) and O-ring (Item 6) from the coil (Item 7).

Inspect the plunger for wear or damage. Replace plunger if worn or damaged.




### **⚠ IMPORTANT**

Remove debris from nozzle components by washing components with clean water.

After extended use the soft plunger seal (Item 1) will wear a groove where the seal impacts the hard orifice seat. Replace plunger if worn or damaged.

As the groove deepens the pressure capacity of the valve will decrease, until the pressure capacity interferes with the operating pressure of the sprayer.

The result is erratic pulsing, often described as “flickering.” SharpShooter will operate normally at lower pressures until replacement parts can be acquired. High operating pressures and abrasive spray solutions will accelerate the wear of the plunger seal material.



Speed/ MPH	Feet/Min	Fixed Distance	Minutes	Seconds	Seconds
2	176	204	1.159090909	69.54545455	70
2.1	184.8	204	1.103896104	66.23376623	66
2.2	193.6	204	1.053719008	63.2231405	63
2.3	202.4	204	1.007905138	60.4743083	60
2.4	211.2	204	0.965909091	57.95454545	58
2.5	220	204	0.927272727	55.63636364	56
2.6	228.8	204	0.891608392	53.4965035	53
2.7	237.6	204	0.858585859	51.51515152	52
2.8	246.4	204	0.827922078	49.67532468	50
2.9	255.2	204	0.799373041	47.96238245	48
3	264	204	0.772727273	46.36363636	46
3.1	272.8	204	0.747800587	44.86803519	45
3.2	281.6	204	0.724431818	43.46590909	43
3.3	290.4	204	0.702479339	42.14876033	42
3.4	299.2	204	0.681818182	40.90909091	41
3.5	308	204	0.662337662	39.74025974	40
3.6	316.8	204	0.643939394	38.63636364	39
3.7	325.6	204	0.626535627	37.59213759	38
3.8	334.4	204	0.610047847	36.60287081	37
3.9	343.2	204	0.594405594	35.66433566	36
4	352	204	0.579545455	34.77272727	35
4.1	360.8	204	0.5654102	33.92461197	34
4.2	369.6	204	0.551948052	33.11688312	33
4.3	378.4	204	0.539112051	32.34672304	32
4.4	387.2	204	0.526859504	31.61157025	32
4.5	396	204	0.515151515	30.90909091	31
4.6	404.8	204	0.503952569	30.23715415	30
4.7	413.6	204	0.493230174	29.59381044	30
4.8	422.4	204	0.482954545	28.97727273	29
4.9	431.2	204	0.47309833	28.38589981	28
5	440	204	0.463636364	27.81818182	28
5.1	448.8	204	0.454545455	27.27272727	27
5.2	457.6	204	0.445804196	26.74825175	27
5.3	466.4	204	0.437392796	26.24356775	26
5.4	475.2	204	0.429292929	25.75757576	26
5.5	484	204	0.421487603	25.2892562	25
5.6	492.8	204	0.413961039	24.83766234	25
5.7	501.6	204	0.406698565	24.40191388	24
5.8	510.4	204	0.39968652	23.98119122	24
5.9	519.2	204	0.392912173	23.57473035	24
6	528	204	0.386363636	23.18181818	23

# BLENDING PULSE TIP SELECTION GUIDE: SPEED RANGE (ENGLISH)



APPLICATION SYSTEMS FOR PROFESSIONALS

Always verify actual spray rates before applying chemicals on the field.  
Use wide-angle tips (110 degrees) and appropriate boom heights to provide 100% nozzle overlap.  
Stay within the recommended speed ranges to prevent skips and inconsistent spray patterns.  
Actual speed range depends on machine design and limitations.

Chart data is based on tip manufacturer's published data. Capstan Ag does not guarantee the accuracy of the tip manufacturer data nor the droplet classification. **DO NOT USE AI TIPS.**  
Operator is responsible for the understanding and proper use of this chart.  
Operator is responsible to follow chemical labels, tip manufacturer and governmental requirements.

Orifice Size	Flow		PSI		Speed Range, mph					
	US gpm	Range	Range	Tip	3 GPA	5 GPA	8 GPA	10 GPA	15 GPA	20 GPA
03	0.208	20	19		5.2 to 20.6	3.1 to 12.4	1.9 to 7.7	1.2 to 6.2	0.8 to 4.1	0.6 to 3.1
	0.255	30	29		6.3 to 25.3	3.8 to 15.2	2.4 to 9.5	1.5 to 7.6	1.0 to 5.1	0.8 to 3.8
	0.295	40	39		7.3 to 29.2	4.4 to 17.5	2.7 to 10.9	1.7 to 8.7	1.2 to 5.8	0.9 to 4.4
	0.329	50	48			4.9 to 19.6	3.1 to 12.2	2.0 to 9.8	1.3 to 6.5	1.0 to 4.9
	0.361	60	58			5.4 to 21.4	3.3 to 13.4	2.1 to 10.7	1.4 to 7.1	1.1 to 5.4
04	0.274	20	19		6.8 to 27.1	4.1 to 16.3	2.5 to 10.2	1.6 to 8.1	1.1 to 5.4	0.8 to 4.1
	0.335	30	28			5.0 to 19.9	3.1 to 12.5	2.0 to 10.0	1.3 to 6.6	1.0 to 5.0
	0.387	40	38			5.8 to 23.0	3.6 to 14.4	2.3 to 11.5	1.5 to 7.7	1.2 to 5.8
	0.433	50	47			6.4 to 25.7	4.0 to 16.1	2.6 to 12.9	1.7 to 8.6	1.3 to 6.4
	0.474	60	56			7.0 to 28.2	4.4 to 17.6	2.8 to 14.1	1.9 to 9.4	1.4 to 7.0
05	0.336	20	18			5.0 to 20.0	3.1 to 12.5	2.0 to 10.0	1.3 to 6.7	1.0 to 5.0
	0.412	30	27			6.1 to 24.5	3.8 to 15.3	2.4 to 12.2	1.6 to 8.2	1.2 to 6.1
	0.476	40	36			7.1 to 28.3	4.4 to 17.7	2.8 to 14.1	1.9 to 9.4	1.4 to 7.1
	0.532	50	45				4.9 to 19.8	3.2 to 15.8	2.1 to 10.5	1.6 to 7.9
	0.583	60	54				5.4 to 21.6	3.5 to 17.3	2.3 to 11.5	1.7 to 8.7
06	0.396	20	17			5.9 to 23.5	3.7 to 14.7	2.4 to 11.8	1.6 to 7.8	1.2 to 5.9
	0.485	30	26			7.2 to 28.8	4.5 to 18.0	2.9 to 14.4	1.9 to 9.6	1.4 to 7.2
	0.560	40	35				5.2 to 20.8	3.3 to 16.6	2.2 to 11.1	1.7 to 8.3
	0.626	50	43				5.8 to 23.2	3.7 to 18.6	2.5 to 12.4	1.9 to 9.3
	0.685	60	52				6.4 to 25.4	4.1 to 20.4	2.7 to 13.6	2.0 to 10.2
08	0.503	20	16				4.7 to 18.7	3.0 to 14.9	2.0 to 10.0	1.5 to 7.5
	0.616	30	24				5.7 to 22.9	3.7 to 18.3	2.4 to 12.2	1.8 to 9.1
	0.711	40	32				6.6 to 26.4	4.2 to 21.1	2.8 to 14.1	2.1 to 10.6
	0.795	50	39				7.4 to 29.5	4.7 to 23.6	3.1 to 15.7	2.4 to 11.8
	0.871	60	47					5.2 to 25.9	3.4 to 17.2	2.6 to 12.9
10	0.728	30	21				6.8 to 27.0	4.3 to 21.6	2.9 to 14.4	2.2 to 10.8
	0.840	40	28					5.0 to 25.0	3.3 to 16.6	2.5 to 12.5
	0.939	50	35					5.6 to 27.9	3.7 to 18.6	2.8 to 14.0
	1.029	60	42					6.1 to 30.6	4.1 to 20.4	3.1 to 15.3
12.5	0.843	30	18					5.0 to 25.0	3.3 to 16.7	2.5 to 12.5
	0.973	40	24					5.8 to 28.9	3.9 to 19.3	2.9 to 14.4
	1.088	50	30						4.3 to 21.5	3.2 to 16.2
	1.192	60	36						4.7 to 23.6	3.5 to 17.7
15	0.933	30	15					5.5 to 27.7	3.7 to 18.5	2.8 to 13.9
	1.078	40	21						4.3 to 21.3	3.2 to 16.0
	1.205	50	26						4.8 to 23.9	3.6 to 17.9
	1.320	60	31						5.2 to 26.1	3.9 to 19.6

**DECLARATION OF CONFORMITY • ДЕКЛАРАЦИЯ ЗА СЪОТВЕТСТВИЕ • PROHLÁŠENÍ O SHODĚ • OVERENSSTEMMELSESERKLÆRING • CONFORMITEITSVERKLARING • VASTAVUSDEKLARATSIOON • VAATIMUSTENMUKAISUUSVAKUUTUS • DECLARATION DE CONFORMITE • KONFORMITÄTSEKTLÄRUNG • ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ • MEGFELELŐSÉGI NYILATKOZAT • DICHIARAZIONE DI CONFORMITÀ • ATBILSTĪBAS DEKLARĀCIJA • ATITIKTIES DEKLARACIJA • DIKJARAZZJONI TAL-KONFORMITÀ • DEKLARACJA ZGODNOŚCI • DECLARAÇÃO DE CONFORMIDADE • DECLARAȚIE DE CONFORMITATE • VYHLÁSENIE O ZHODE • IZJAVA O SKLADNOSTI • DECLARACIÓN DE CONFORMIDAD • DEKLARATION OM ÖVERENSSTÄMMELSE**

<p>Business name and full address of the manufacturer • Търговско име и пълен адрес на производителя • Obchodní jméno a plná adresa výrobce • Producentens firmanavn og fulde adresse • Bedrijfsnaam en volledig adres van de fabrikant • Tootja ärimini ja täielik address • Valmistajan toimintiniimi ja täydellinen osoite • Nom commercial et adresse complète du fabricant • Firmenname und vollständige Adresse des Herstellers • Εταιρεία και ταχυδρομική διεύθυνση κατασκευαστή • A gyártó üzleti neve és teljes címe • Ragione sociale e indirizzo completo del fabbricante • Uzņēmuma nosaukums un pilna ražotāja adrese • Verslo pavadinimas ir pilnas gamintojo adresas • Isem kummerdjali u indirizz shih tal-fabrikant • Nazwa firmy i pełny adres producenta • Nome da empresa e endereço completo do fabricante • Denumirea comercială și adresa completă a producătorului • Obchodný názov a úplná adresa výrobcu • Naziv podjetja in polni naslov proizvajalca • Nombre de la empresa y dirección completa del fabricante • Tillverkarens företagsnamn och kompletta adress</p>	<p align="center"><b>Smithco Inc. 34 West Avenue Wayne, PA USA 19087-3311</b></p>
<p>Product Code • Код на продукта • Kód výrobku • Produktkode • Productcode • Toote kood • Tuotekoodi • Code produit • Produktcode • Κυβικός προότυπος • Termékkód • Codice prodotto • Produkta kods • Produkto kodas • Kodíci tal-Prodott • Kod produktu • Código do Produto • Cod produs • Kód výrobku • Označka výrobku • Código de producto • Produktkod</p>	<p align="center"><b>31-000</b></p>
<p>Machine Name • Наименование на машината • Název stroje • Maskinnavn • Machinenaam • Masina nimi • Laitteen nimi • Nom de la machine • Maschinenbezeichnung • Ονομασία μηχανήματος • Gégnév • Denominazione della macchina • Iekārtas nosaukums • Mašinos pavadinimas • Isem tal-Magna • Nazwa urządzenia • Nome da Máquina • Numele echipamentului • Název stroja • Naziv stroja • Nombre de la máquina • Maskinens namn</p>	<p align="center"><b>Spray Star 3180</b></p>
<p>Designation • Предназначение • Oznáčení • Betegnelse • Benaming • Nimetus • Tuypimerkintä • Pažymėjimas • Bezeichnung • Χαρακτηρισμός • Megnevezés • Funzione • Apzīmējums • Lithuanian • Denominazzjoni • Oznaczenie • Designação • Specificație • Označenie • Nomen stroja • Descripción • Beteckning</p>	<p align="center"><b>Turf Sprayer</b></p>
<p>Serial Number • Серийн номер • Sériové číslo • Seriennummer • Seriennummer • Serierianumber • Valmistusnumero • Numéro de série • Seriennummer • Σειριακός αριθμός • Sorozatszám • Numero de serie • Sérijas numurs • Serijos numeris • Numru Serjali • Numer serjnyj • Número de Série • Număr de serie • Sériovské číslo • Serijska številka • Número de serie • Seriennummer</p>	<p align="center"><b>300G066</b></p>
<p>Engine • Двигател • Motor • Motor • Motor • Mootor • Mootori • Moteur • Motor • Μηχανή • Modulnė • Motore • Dzinējs • Variklis • Saha Naeta Installata • Silnik • Motor • Motor • Motor • Motor • Motor • Motor</p>	<p align="center"><b>kubota V1505</b></p>
<p>Net Installed Power • Нетя инсталтирана мощност • Čistý instalovaný výkon • Installeret nettoeffekt • Netto geïnstalleerd vermogen • Installeeritud netovõimsus • Asennettu nettoteho • Puissance nominale nette • Installierte Nettoleistung • Καθαρή εγκατεστημένη ισχύς • Nettó beépített teljesítmény • Potenza netta installata • Paredzētā tīkla jauda • Grynoji galia • Wisa' tal-Qlugh • Moc zainstalowana netto • Pot ência instalada • Puterea instalată netă • Čistý inštalovaný výkon • Neto vgrajena moč • Potencia instalada neta • Nettoeffekt</p>	<p align="center"><b>26.6 kW</b></p>
<p>Conforms to Directives • В съответствие с директивите • Splūuje podminky smérnic • Er i overensstemmelse med direktiver • Voldoet aan de richtlijnen • Vastab direktiivide • Direktiivien mukainen • Conforme aux directives • Entspricht Richtlinien • Ακολουθείτε πιστά τις Οδηγίες • Megfelel az irányelveknek • Conforme alle Direttive • Atbilst direktīvām • Atitinka direktyvų reikalavimus • Valutazzjoni tal-Konformità • Dyrektywy związane • Cumpre as Directivas • Respectă Directivale • Je v súlade so smernicami • Skladnost z direktivami • Cumpie con las Directivas • Uppfyller direktiv</p>	<p align="center"><b>2006/42/EC; 2000/14/EC Annex VI - Part 1</b></p>
<p>Conformity Assessment • Оценка за съответствие • Hodnocení plnění podmínek • Overensstemmelsesvurdering • Conformiteitsbeoordeling • Vastavushindamine • Vaatimustenmukaisuuden arviointi • Evaluation de conformité • Konformitätsbeurteilung • Διαπίστωση Συμμόρφωσης • Megfelelőség-értékelés • Valutazione della conformità • Atbilstības novērtējums • Atitikties ivertinimas • Livell tal-Qawwa tal-Foss Imkejjel • Ocena zgodności • Avaliação de Conformidade • Evaluarea conformității • Vyhodnotenie zhodnosti • Ocena skladnosti • Evaluación de conformidad • Bedömning av överensstämmelse</p>	<p align="center"><b>2006/42/EC Annex VIII</b></p>
<p>Measured Sound Power Level • Измерено ниво на звукова мощност • Naměřený akustický výkon • Målte lydstyrkeniveau • Gemeten geluidsniveau • Mëdëdetud hehivõimsuse tase • Mitattu äänitehotaso • Niveau de puissance sonore mesuré • Gemessener Schalldruckpegel • Στοβρισμένο επίπεδο ηχητικής ισχύος • Mért hangteljesítményszint • Livello di potenza sonora misurato • Izm ģrētais skaņas jaudas līmenis • Izmērotais garso stiprumo līgis • Livell tal-Qawwa tal-Foss Iggarranti • Moc akustyczna mierzona • Nivel sonoro medido • Nivelul măsurat al puterii acustice • Nameranā hlāidna akustiského výkonu • Izmerjena raven zvočne moči • Nivel de potencia sonora medido • Uppmätt ljudeffektnivå</p>	<p align="center"><b>98dB(A)Lwa</b></p>
<p>Guaranteed Sound Power Level • Гарантирано ниво на звукова мощност • Garantovaný akustický výkon • Garanteret lydstyrkeniveau • Gegarandeerd geluidsniveau • Garanteeritud hehivõimsuse tase • Taattu äänitehotaso • Niveau de puissance sonore garanti • Garanterter Schalldruckpegel • Εγγυημένο επίπεδο ηχητικής ισχύος • Szavatolt hangteljesítményszint • Livello di potenza sonora garantito • Garant ģrētais skaņas jaudas līmenis • Garantuotais garso stiprumo līgis • Livell tal-Qawwa tal-Foss Iggarranti • Moc akustyczna gwarantowana • Nivel sonoro garantido • Nivelul garantat al puterii acustice • Garantovaná hlāidna akustiského výkonu • Zajāmčēna raven zvočne moči • Nivel de potencia sonora garantizado • Garanterad ljudeffektnivå</p>	<p align="center"><b>100 dB(A)Lwa</b></p>
<p>Conformity Assessment Procedure (Noise) • Оценка за съответствие на процедурата (Шум) • Postup hodnocení plnění podmínek (hluk) • Procedure for overensstemmelsesvurdering (Støj) • Procedure van de conformiteitsbeoordeling (geluid) • Vastavushindamismenetlus (müra) • Vaatimustenmukaisuuden arviointimenetelmä (Melu) • Procédure d'évaluation de conformité (bruit) • Konformitätsbeurteilungsverfahren (Geräusch) • Διαδικασία Αξιολόγησης Συμμόρφωσης (Θόρυβος) • Megfelelőség-értékelési eljárás (Zaj) • Procedura di valutazione della conformità (rumore) • Atbilstības novērtējuma procedūra (troksnis) • Atitikties ivertinimo procedūra (garsas) • Procedura tal-Valutazzjoni tal-Konformità (Hoss) • Procedura oceny zgodności (poziom hałas) • Procedo de avaliação de conformidade (nivel sonoro) • Procedura de evaluare a conformității (zgomot) • Postup vyhodnocovania zhodnosti (hluk) • Postopek za ugotavljanje skladnosti (hrup) • Procedimiento de evaluación de conformidad (ruido) • Procedur för bedömning av överensstämmelse (buller)</p>	<p align="center"><b>2000/14/EC Annex VI Part 1</b></p>
<p>UK Notified Body for 2000/14/EC • Нотифициран орган в Обединеното кралство за 2000/14/EO • Ufad certifikovaný podle směrnice č. 2000/14/EC • Det britiske bemyndigede organ for 2001/14/EF • Engels adviesorgaan voor 2000/14/EG • Ühendkuningriigi teavitatud asutus direktiivi 2000/14/EÜ mõistes • Direktiivin 2000/14/EY mukainen ilmoitettu tarkastuslaitos Isonsa-Britanniassa • Organisme notifié concernant la directive 2000/14/CE • Britische benannte Stelle für 2000/14/EG • Κοινοποιημένος Οργανισμός Ηνωμένου Βασιλείου για 2000/14/ΕΚ • 2000/14/ΕΚ – egyesült királyságbeli bejelentett szervezet • Organismo Notificato in GB per 2000/14/CE • 2000/14/ΕΚ AK re gistrētā organizācija • JK notifikuotais įstaigos 2000/14/EC • Korp Notifikat tar-Renju Unit ghal 2000/14/KE • Dopuszczona jednostka badawcza w Wielkiej Brytanii wg 2000/14/WE • Entidade notificada no Reino Unido para 2000/14/CE • Organism notifiat în Marea Britanie pentru 2000/14/CE • Notifikovaný orgán Spojeného královstva pre směrnici 2000/14/ES • Britanski prijavljeni organ za 2000/14/ES • Cuerpo notificado en el Reino Unido para 2000/14/CE • Anmält organ för 2000/14/EG i Storbritannien</p>	<p align="center"><b>Smithco West Inc. 200 West Poplar Avenue Cameron, WI 54822 USA</b></p>
<p>Operator Ear Noise Level • Оператор на нивото на доловим от ухото шум • Hladina hluku v oblasti uší operátora • Støjniveau i førers ørehøjde • Geluidsniveau oor bestuurder • Mērītase operatori kārvas • Melutaso käyttöajan korvan kohdalla • Niveau de bruit à hauteur des oreilles de l'opérateur • Schallpegel am Bedienerohr • Επίπεδο θορύβου σε λειτουργία • A kezelő fülénél mért zajszint • Livello di potenza sonora all'orecchio dell'operatore • Trokšņa līmenis pie operatora auss • Dirbančiojo su mašina patiriamu triukšmo lygis • Livell tal-Widna fil-Widna tal-Operatur • Dopuszczalny poziom hałasu dla operatora • Nivel sonoro nos ouvidos do operador • Nivelul zgomotului la urechea operatorului • Hladina hluku pôsobiacna na sluch operátora • Raven hrupa pri užesu upravljavca • Nivel sonoro en el oído del operador • Ljudnivå vid förarens öra</p>	<p align="center"><b>98 dB(A)Lwa (2006/42/EC)</b></p>

<p>Harmonised standards used • Използвани хармонизирани стандарти • Použité harmonizované normy • Brugte harmoniserede standarder • Gebruikte geharmoniseerde standaards • Kasutatud ühtlustatud standardid • Käytetyt yhdenmukaistetut standardit • Normes harmonisées utilisées • Angewandte harmonisierte Normen • Ενοποιημένα πρότυπα που χρησιμοποιήθηκαν • Harmonizált szabványok • Standard armonizzati applicati • Izmantotie saskapotie standarti • Panaudoti suderinti standartai • Standardi armonizzati usati • Normy spójne powiązane • Normas harmonizadas usadas • Standardele armonizate utilizate • Použité harmonizované normy • Uporabljeni usklajeni standardi • Estándares armonizados utilizados • Harmoniserade standarder som används</p>	<p>BS EN ISO 12100-1:2003 BS EN ISO 12100-2:2003 BS EN ISO 13857 BS EN 349: 1993+A1:2008 BS 6356: P8 BS 6356:P5 BS EN 907</p>
<p>Technical standards and specifications used • Използвани технически стандарти и спецификации • Použité technické normy a specifikace • Brugte tekniske standarder og specifikationer • Gebruikte technische standaards en specificaties • Kasutatud tehnilised standardid ja spetsifikatsioonid • Käytetyt tekniset standardit ja eritelmät • Spécifications et normes techniques utilisées • Angewandte technische Normen und Spezifikationen • Τεχνικά πρότυπα και προδιαγραφές που χρησιμοποιήθηκαν • Műszaki szabványok és specifikációk • Standard tecnici e specifiche applicati • Izmantotie tehnikie standarti un specifikācijas • Panaudoti techniniai standartai ir techninė informacija • Standardu u specifikacijų lietuvių ir anglų kalbomis • Miejscze i data wystawienia deklaracji • Local e data da declaração • Local și data declarației • Miesto a dátum vyhlášení • Kraj in datum izjave • Lugar y fecha de la declaración • Plats och datum för deklarationen</p>	<p>ISO 21299 2002/44/EC SAE J1362</p>
<p>The place and date of the declaration • Място и дата на декларацията • Misto a datum prohlášení • Sted og dato for erklæringen • Plaats en datum van de verklaring • Deklaratsiooni väljastamise koht ja kuupäev • Vakuutuksen paikka ja päivämäärä • Lieu et date de la déclaration • Ort und Datum der Erklärung • Τόπος και ημερομηνία δήλωσης • A nyilatkozat kelte (hely és idő) • Luogo e data della dichiarazione • Deklarācijas vieta un datums • Deklarācijas vieta ir data • Il-post u d-data tad-dikjarazzjoni • Miejsce i data wystawienia deklaracji • Local e data da declaração • Local și data declarației • Miesto a dátum vyhlášení • Kraj in datum izjave • Lugar y fecha de la declaración • Plats och datum för deklarationen</p>	<p>Smithco West Inc. 200 West Poplar Avenue Cameron, WI 54822 USA 24-Jun -09</p>
<p>Signature of the person empowered to draw up the declaration on behalf of the manufacturer, holds the technical documentation and is authorised to compile the technical file, and who is established in the Community. Подпис на човека, упълномощен да състави декларацията от името на производителя, който поддържа техническата документация и е оторизиран да изготви техническия файл и е регистриран в общността. Podpis osoby oprávněné sestavit prohlášení jménem výrobce, držet technickou dokumentaci a osoby oprávněné sestavit technické soubory a založené v rámci Evropského společenství. Underskrift af personen, der har fuldmagt til at udarbejde erklæringen på vegne af producenten, der er indehaver af dokumentationen og er bemyndiget til at udarbejde den tekniske journal, og som er baseret i nærområdet. Handtekening van de persoon die bevoegd is de verklaring namens de fabrikant te tekenen, de technisch documentatie bewaart en bevoegd is om het technische bestand samen te stellen, en die is gevestigd in het Woongebied. Ühenduse registrisse kantud isiku allkirri, kes on volitatud tootja nimel deklaratsiooni koostama, kes omab tehnilisdokumentatsiooni ja kellel on õigus koostada tehniline toimik. Sen henkilöön allekirjoitus, jolla on valmistajan valtuutus vakuutuksen laadintaan, jolla on hallussaan teknisetasiakirjat, joka on valtuutettu laatimaan tekniset asiakirjat ja joka on sijoittautunut yhteisöön. Signature de la personne habilitée à rédiger la déclaration au nom du fabricant, à détenir la documentation technique, à compiler les fichiers techniques et qui est implantée dans la Communauté. Unterschrift der Person, die berechtigt ist, die Erklärung im Namen des Herstellers abzugeben, die dietechnischen Unterlagen aufbewahrt und berechtigt ist, die technischen Unterlagen zusammenzustellen, und die in der Gemeinschaft niedergelassen ist. Υπογραφή στόμου εξουσιοδοτημένου για την σύνταξη της δήλωσης εκ μέρους του κατασκευαστή, ο οποίος κατέχει την τεχνική έκθεση και έχει την εξουσιοδότηση να ταξινομήσει τον τεχνικό φάκελο και ο οποίος είναι ενοποιημένος στην Κοινότητα. A gyártó nevében meghatalmazott személy, akinek jogában áll módosítani a nyilatkozatot, a műszakidokumentációt őrizi, engedélyvel rendelkezik a műszaki fájllal összeállításához, és aki a közösségben telepedett személy. Firma della persona autorizzata a redigere la dichiarazione a nome del fabbricante, in possesso della documentazione tecnica ed autorizzata a sostituire il fascicolo tecnico, che deve essere stabilita nella Comunità. T. ás personas paraksts, kura ir pilnvarota deklarācijas sastādīšanai ražotāja vārdā, kurai ir tehniskā dokumentācija, kura ir pilnvarota sagatavot tehnisko reģistru un kura ir apstiprināta Kopienā. Asmuo, kuris yra gana žinomas, kuriam gamintojas suteikė įgaliojimus sudaryti šią deklaraciją, ir kuris įspasirašė, turi visą techninę informaciją ir yra įgaliojotas sudaryti techninės informacijos dokumentą. Il-firma tal-persuna awtorizzata li tfassal id-dikjarazzjoni fisem il-fabrikant, ghandha d-dokumentazzjoniteknika u hija awtorizzata li tikkompila l-fajjl tekniku u li hija stabblita fil-Komunità. Podpis osoby upoważnionej do sporządzenia deklaracji w imieniu producenta, przechowującej dokumentację techniczną, upoważniona do stworzenia dokumentacji technicznej oraz wyznaczonej ds. wspólnotowych. Assinatura da pessoa com poderes para emitir a declaração em nome do fabricante, que possui a documentação técnica, que está autorizada a compilar o processo técnico e que está estabelecida na Comunidade. Semnătura persoanei împuternicite să elaboreze declarația în numele producătorului, care deține documentația tehnică, este autorizată să compileze dosarul tehnic și este stabilită în Comunitate. Podpis osoby poverenej vystavenim vyhlášení v mene výrobce, ktorá má technickú dokumentáciu a je oprávnená spracovať technické podklady a ktorá je umiestnená v Spoločenstve. Podpis osebe, pooblašene za izdelavo izjave v imenu proizvajalca, ki ima tehnično dokumentacijo in lahko sestavlja spis tehnične dokumentacije, ter ima sedež v Skupnosti. Firma de la persona responsabile de la declaración en nombre del fabricante, que posee la documentación técnica y está autorizada para recopilar el archivo técnico y que está establecido en la Comunidad. Undertecknas av den som bemyndigad att upprätta deklarationen i tillverkarens vägnar, innehar den tekniskadokumentationen och är bemyndigad att sammanställa den tekniska informationen och som är etablerad igemenskapen.</p>	<p> 2006/42/EC Annex II 1A: 2 Tim Lansdell Technical Director 19th March 2009 Ransomes Jacobsen Limited West Road, Ransomes Europark, Ipswich, England, IP3 9TT</p> <p> 2006/42/EC Annex II 1A: 10 Dawn Bryngelson Technical Documentation Advisor Smithco Inc. 34 West Avenue Wayne, PA USA 19087-3311 10-Dec -09</p>
<p>Certificate Number • Номер на сертификат • Číslo osvědčení • Certifikatnummer • Certificaatnummer • Sertifikaadi number • Huvkäysntänumero • Numéro de certificat • Bescheinigungsnummer • Αριθμός Πιστοποιητικού • Hitelesítési szám • Numero del certificato • Sertifikata numurs • Sertifikato numeris • Numru tač-Certifikat • Numer certyfikatu • Número do Certificado • Număr certificat • Číslo osvedčenia • Številka certifikata • Número de certificado • Certifikatsnummer</p>	<p>310002009-1</p>

- |                       |                              |                             |                    |                         |                        |                     |                         |                          |                       |                      |
|-----------------------|------------------------------|-----------------------------|--------------------|-------------------------|------------------------|---------------------|-------------------------|--------------------------|-----------------------|----------------------|
| <b>GB</b><br>English  | <b>BG</b><br>български       | <b>CZ</b><br>čeština        | <b>DK</b><br>dansk | <b>NL</b><br>Nederlands | <b>EE</b><br>eesti     | <b>FI</b><br>suomi  | <b>FR</b><br>français   | <b>DE</b><br>Deutsch     | <b>GR</b><br>Ελληνικά | <b>HU</b><br>magyar  |
| <b>IT</b><br>italiano | <b>LV</b><br>latviešu valoda | <b>LT</b><br>lietuvių kalba | <b>MT</b><br>Malti | <b>PL</b><br>polski     | <b>PT</b><br>português | <b>RO</b><br>Română | <b>SK</b><br>slovenčina | <b>SI</b><br>slovenščina | <b>ES</b><br>español  | <b>SE</b><br>Svenska |





## QUICK REFERENCE REPLACEMENT PARTS

### REPLACEMENT FILTERS

72-146	Hydraulic Oil Filter Assembly
60-334	Replacement Element
30-042-05	Air Cleaner Cartridge
13-488	Key Switch
30-042-08	Fuel Filter Element
30-042-09	Engine Oil Filter
77-217	Exhaust Muffler Gasket

### REPLACEMENT BELTS

30-137	Spray Pump Belt
30-042-11	Fan Belt

### SEAL KITS

15-301	Power Steering Orbital Motor
15-301-01	Seal Kit
30-101	Wheel Motors
30-101-11	Seal Kit
30-102	Hydrostatic Pump
33-058-01	Seal Kit
76-197	Gear Pump
76-197-08	Seal Kit
15-839	Hydraulic Cylinder (steering)
14-531	Seal Kit

### FLUIDS

Engine Oil	SAE 10W-40 API Service SJ or higher Motor Oil
Hydraulic Fluid	SAE 10W-40 API Service SJ or higher Motor Oil
Radiator	1.06 Gal 50/50 Antifreeze/water mixture

### OTHER PARTS

16-953	Hinged Cover On Tank with Gasket
16-953-01	Gasket For Cover
16-169	Strainer Basket
15-818	#75 Fitting O-ring
15-817	#50 Fitting O-ring
20-663	Tank Lid Gasket

# The Smithco Commercial Products Two-Year Limited Warranty

Smithco, Inc. (Smithco) warrants your 2007 or newer Smithco Commercial Product ("Product") purchased after January 1, 2007, to be free from defects in materials or workmanship for the period of time listed below. Where a warrantable condition exists, Smithco will repair the Product at no cost to you including diagnosis, labor (at the Smithco standard labor rate, subject to the Smithco flat rate schedule), and parts.

## Warranty Duration is:

- (1) Two years, 1500 operational hours\* from the date of delivery to the original purchaser or three years from the date of original manufacturer of the product, whichever occurs first. (\*Products equipped with hour meter).
- (2) Products used in rental situations are covered for 90 days from date of delivery to original user/ renter.

## Owner Responsibilities:

As the Product owner, you are responsible for required maintenance and adjustments stated in your Owner's Manual. Failure to perform required maintenance and adjustments can be grounds for disallowing a warranty claim. **You are particularly responsible to train all present and future operators of this product on the safe operation of this product at your location.**

## Instructions for Obtaining Warranty Service:

You are responsible for notifying the Authorized Smithco Products Distributor from whom you purchased the Product as soon as you believe a warrantable condition exists and not later than 30 days from discovery of the condition.

If you need help locating an Authorized Smithco Distributor, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

Smithco Product Support Department  
200 W Poplar PO Box 487  
Cameron, Wisconsin 54822

Telephone: 1-800-891-9435

E-Mail: [ProductSupport@smithco.com](mailto:ProductSupport@smithco.com)

## Maintenance Parts:

Parts scheduled for replacement as required maintenance ("Maintenance Parts"), are warranted for the period of time up to the scheduled replacement time for that part.

### Items/Conditions Not Covered:



Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. The items/conditions listed below are not covered by this warranty:



Product failures which result from the use of non-Smithco replacement parts, or from installation and use of add-on, modified, or unapproved accessories are not covered.



Product failures which result from failure to perform required maintenance and/or adjustments are not covered.



Product failures that result from operating the Product in an abusive, negligent or reckless manner are not covered.



This warranty does not apply to parts subject to consumption through use, unless found to be defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to: blades, tines, teeth, scarifiers, rakes, plates, wear plates, castor wheels, tires, batteries, filters, belts, nozzles, etc.



This warranty does not apply to failures caused by outside influence. Items considered to be outside influence include, but are not limited to, weather, storage practices, contamination, use of unapproved coolants, lubricants, additives, or chemicals, etc.



This warranty does not apply to normal “wear and tear” items. Normal “Wear and Tear” includes, but is not limited to, damage to seats due to wear or abrasion, worn painted surfaces, scratched decals or windows, etc.



Smithco may require the return of failed parts or components in order to determine the validity of any warranty claim.



Smithco will not be obligated to replace components of other manufacturers if inspection by the original component manufacturer indicates that failure was due to normal wear and tear, expected consumption through use or improper care or service.

#### **Other Legal Disclaimers:**

The above remedy for product defects through repair or replacement by an authorized Smithco distributor or dealer is the purchaser’s sole remedy for any defect. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**THERE ARE NO OTHER EXPRESS WARRANTIES OTHER THAN THOSE SET FORTH ABOVE. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE DURATION OF THE LIMITED WARRANTIES CONTAINED HEREIN.**

Some states may not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

**THE SMITHCO COMPANY IS NOT LIABLE FOR INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE USE OF THE PRODUCT, INCLUDING ANY COST OR EXPENSE OF PROVIDING A SUBSTITUTE PRODUCT OR SERVICE DURING PERIODS OF MALFUNCTION OR NON-USE.**

Some states may not allow the exclusion of indirect, incidental or consequential damages, so the above exclusion may not apply to you.

**Smithco neither assumes, nor authorizes any person to assume for it, any other liability in connection with the sale or use of this product.**

**SMITHCO, INC.**

**Wayne, PA 19087**

